

Installation Instructions

Tools: One 7/16" wrench.

1. Mount the bracket "V" cut down onto the top side of your front rack, or handlebar.
2. Place the u-bolt under the rack, or handlebar and up through the bracket.
3. Level the bracket.
4. Put lock washers and nuts on the u-bolt and hand tighten.
5. Insert the cup holder rod into hole in the bracket.
6. Adjust to fit your riding style.
7. Tighten the nuts on the side of the bracket.
8. Install the rubber protective caps onto the u-bolt nuts.

You're done! Happy riding!

